

**SAFETY INFORMATION**

Released Date: 2021-03-24

Please read and understand this entire manual before attempting to assemble, install or operate the product.


**WARNING**

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

**CAUTION**

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

**TOOLS REQUIRED**




**CARE AND MAINTENANCE**


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quozel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at [www.quozel.com](http://www.quozel.com).

**PACKAGE CONTENTS**



**MOUNTING HARDWARE**



# INSTALLATION

**1 Adjust Cord Length:**  
 Fixture Height Adjustable 15.5" to 101.5"

Unlock set screw on the cord relief and slide the safety clip to adjust the cord length according to desired hanging height. Always tighten the set screw after adjustment.

Safety Clip  
 Cord Relief  
 Set Screw  
 Cord

**2 Install Crossbar**

**3 Wiring**

White wire from supply  
 White wire from fixture  
 Black (or red) wire from supply  
 Black wire from fixture  
 Ground wire from supply  
 Ground wire from fixture  
 Green ground screw

**4 Install Ceiling Canopy to Crossbar**

**5 Install Ring**

**6 Install Shade**

**7 Install Bulb**

Install the correct bulb referring to fixture markings and/or labels for maximum wattage.

**Recommended Bulb Type (not included):**

BULB BASE TYPE  
 Medium (E26)

BULB TYPE  
 TYPE A

100W MAX

Your installation is now complete! Restore electricity and save this sheet for future reference.