

Please go to [www.quoizel.com](http://www.quoizel.com) for product cleaning tips. Go to the **Care + Maintenance** selection.

**Tools Required:** Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

**Light Source:** LED 21W

**Estimated Assembly Time:** 20-30 minutes


**Preparation:** Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

### ⚠ Warnings and Cautions


Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

### Package Contents




### Hardware Contents



### STEP 1 – Attach Mounting Bracket to Outlet Box

- Attach the Mounting Bracket (AA) onto the outlet box. Align one set of holes on the Mounting Bracket (AA) to mounting holes on the outlet box and make two marks on the ceiling from keyholes on the flat strap of the Mounting Bracket (AA).
- Remove the Mounting Bracket (AA) and drill proper holes on the ceiling from marks. Insert Wall Anchors (CC) into the holes properly.




### (Step 1 Continued)

- Attach the Mounting Bracket (AA) to outlet box. Secure by threading outlet box screws (not supplied) into mounting holes on the outlet box and threading Self-tapping Screws (EE) with Washers (DD) into Wall Anchors (CC). Hand tighten until snug.


### STEP 2 – Wire Connections

- Wrap bare or green ground wire around green ground screw on the crossbar, no less than 2 inches from the end of the wire. Tighten the green ground screw.
- Use standard wire connectors (not included) to make all wire connections. Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.



### STEP 3 – Attach Fixture Body to Mounting Bracket

- Attach the Fixture Body (D) to the Mounting Bracket (AA) and line up the holes on the side of the ceiling canopy to the mounting holes on the Mounting Bracket (AA). Secure them with Mounting Screws (BB). Tighten until snug.
- Remove protective film from Ceiling Canopy carefully.




**Thank you for purchasing a Quoizel product.**  
**Need assistance with parts or assembly? Call Quoizel customer service at 1-800-645-3184**  
**or visit us on-line at [www.quoizel.com](http://www.quoizel.com)**

**STEP 4 - Install Shades**


A. (Refer to SHADE ORIENTATION) Thread Shades (A/B/C) to sockets and hand tighten until snug.

Your fixture is now assembled and ready to use. Enjoy!

Figure 4






**SHADE ORIENTATION**



PCSH1614BCH

FINISH: BLACK CHROME

NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/4"



Thank you for purchasing a Quoizel product.  
Need assistance with parts or assembly? Call Quoizel customer service at 1-800-645-3184  
or visit us on-line at [www.quoizel.com](http://www.quoizel.com)